

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5

130

Vehicle Speed (V)	V ₁	V ₂	V ₃	V _n
Steering Angle Conversion Ratio (α)	α ₁	α ₂	α ₃	α _n

$$\alpha = \theta / \phi$$

φ : Handle Shaft Angular Position

θ : Steering Shaft Angular Position

FIG. 6




FIG. 7

131

$\Delta \theta$	V_s	V_{s1}	V_{s2}	V_{s3}	V_{s4}	...	V_{sn}
$\Delta \theta_1$	η_{11}	η_{12}	η_{13}	η_{14}	η_{1n}
$\Delta \theta_2$	η_{21}	η_{22}	η_{23}	η_{24}	η_{2n}
$\Delta \theta_3$	η_{31}	η_{32}	η_{33}	η_{34}	η_{3n}
$\Delta \theta_4$	η_{41}	η_{42}	η_{43}	η_{44}	η_{4n}
:	:	:	:	:	⋮	⋮	⋮
$\Delta \theta_m$	η_{m1}	η_{m2}	η_{m3}	η_{m4}	η_{mn}

η : Duty Ratio

$$\Delta \theta = \theta' - \theta$$

θ' : Target Steering Shaft Angular Position

θ : Present Steering Shaft Angular Position

FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12

